

**FOLD HERE
PLIER ICI
DOBLE AQUI**

BACKSET 70mm (2-3/4")
DISTANCE D'ENTRÉE 70mm (2-3/4")
PARA CERROJO DE 70mm (2-3/4")

BACKSET 60mm (2-3/8")
DISTANCE D'ENTRÉE 60mm (2-3/8")
PARA CERROJO DE 60mm (2-3/8")

Ø51mm (2")

60 51 45 40 35
2-3/8" 2" 1-3/4" 1-9/16" 1-3/8"

drill 25.4mm (1") hole
at center of door edge

percez un trou de 25.4
mm (1") dans le centre
du rebord de la porte

Haga una perforacion
de 1" al centro del
canto de la puerta.

CENTER TO CENTER 127mm (5")
CENTRE À CENTRE 127mm (5")
CENTRO A CENTRO 127mm (5")

Ø51mm (2")

60 51 45 40 35
2-3/8" 2" 1-3/4" 1-9/16" 1-3/8"

drill 25.4mm (1") hole
at center of door edge

percez un trou de 25.4
mm (1") dans le centre
du rebord de la porte

Haga una perforacion
de 1" al centro del
canto de la puerta.

CENTER TO CENTER 214mm (8-13/32")
CENTRE À CENTRE 214mm (8-13/32")
CENTRO A CENTRO 214mm (8-13/32")

MARK HEIGHT 914mm (36") FROM FLOOR TO CENTER
914mm (36") DU PLANCHER AU CENTRE
ALTURA RECOMENDADA DE PISO A CENTRO INDICA 914 mm(36")

Ø10mm (3/8")