



FOR CUTOUTS ON INSIDE FACE OF DOOR
SEE DEVICE TEMPLATE.

NOTE: IT IS RECOMMENDED THE MOUNTING
HOLES BE PREPARED IN THE FIELD

230TP & 230TP-BE TRIM



NOTES: SEE MASTER SHEET NO. 10001 FOR SUGGESTED REINFORCING

TEMPLATE
NUMBER:

20038_1

DATE:

8-18-98