



**Notes:**

1. Minimum Stile Width 4-1/2(114).
2. For door reinforcements see template 7400-0000. Unreinforced doors require optional SNB to mount devices.
3. Unless otherwise specified, door preparation and dimensional tolerances must conform to ANSI A115.1. Lock support required as shown.
4. For outside trim preparation see appropriate trim template.
5. Prepare mounting holes when installing the device.
6. LHR active pair shown. Preparation is typical for both door hands.
7. Dimensions are in inches (mm). Do not scale drawing.
8. Holes for optional SNB: 9/32(7.00)Dia. inside door face; 3/8(9.50) Dia. outside door face.
9. Dimensions given about a centerline are symmetrical.
10. Device mount to hinge stile (not shown) requires holes location and preparation during device installation.
11. For Electrical device suffixes "-Safe", "-Secure", "-O-", or "-S-": 1/2 (12.70) diameter, this face, plus prep shown on template 7477-0001.
12. For electrical device suffixes "-B", "-G", or "-P" also see template 7477-0001.

**7130, 7135 & 7130F Mortise Exit Devices  
with ANSI A115.1 Strike**  
Application for Pair of Metal Doors without Mullion



**Yale Commercial Locks and Hardware**

www.yalecommercial.com

TEMPLATE NUMBER

**7470-0031**

DATE

**8-99**