

## Notes:

- 1. Do not scale drawing.
- 2. Dimensions are in inches (mm).
- 3. Minimum Stile Width: 2 (51).
- 4. Maximum door Width: 42 (1067)
- 5. Prepare mounting holes when installing the hardware.
- 6. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the hardware
- Holes for optional SNB:9/32 (7.00) Dia.Inside door face; 3/8 (9.50) Dia. Outside door face.
- 8. Provide door stiffeners as needed to prevent door collapse due to installation with power tools, door use, or abuse.

720DB Dummy Push Bar Application for Metal Door



www.yalelocks.com

TEMPLATE NUMBER

**Yale** 

7470-0720

An ASSA ABLOY Group brand

03-11

DATE