
Notes:

- Backset is measured from centerline of bevel which is centerpoint of door thickness.
- 2. (*) When preparing doors for lead wrapped locks, add 1/8" (3.2) to dimensions marked (*) to allow proper clearance.
- 3. Dimensions given in inches and (mm).
- 4. Frame prep meets ANSI standards A115.5 (steel) and A115.W8 (wood) for deadlock strikes.

| Template Cross Reference | |
|--------------------------|----------|
| Description | Template |
| 240L08 ANSI Strike | T30657 |

| Lock Function | Required Holes | | |
|-----------------|----------------|---|---|
| | Α | В | С |
| DL4111 | • | | |
| DL4112 | | • | |
| DL4113 & DL4117 | • | | • |
| DL4122 | | • | • |
| DI 4160 | | | |



RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

DL4100 Series

Mortise Deadlock

Corbin 72°
RUSSWIN 22°
ASSA ABLOY

www.corbinrusswin.com

SUPERSEDES DO NOT SCALE DRAWING

T31189

02-11