

**Notes:**

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. Minimum Stile Width: 2 (51).
4. Maximum door Width: 42 (1067)
5. Prepare mounting holes when installing the hardware.
6. For recommended door reinforcements see template T30800. Unreinforced doors require SNB option to mount the hardware
7. Holes for optional SNB: 9/32 (7.00) Dia. Inside door face;
3/8 (9.50) Dia. Outside door face.
8. Provide door stiffeners as needed to prevent door collapse due to installation with power tools, door use, or abuse.

ED5000DB Dummy Push Bar
Application for Metal Door

Corbin
Russwin[®]
www.corbinrusswin.com

SUPERSEDES T30871-2 DO NOT SCALE DRAWING

TEMPLATE NUMBER T30871-3 DATE 8-99