



Product selection grid showing various handle and knob designs:

- ★ 506, ★ 506F
- ★ 508, ★ 508F, ★ 509, ★ 509F
- 503, 503F
- 507, 507F
- 502, ■ 502F
- 504, ■ 504F
- 505, ■ 505F

(See Note 7)

★ Leverhandle design prefixes "AR", "AU", "CR", "JN", "MO", "PB", "PN", or "VI".

■ Knob design prefixes "BR", "CO", "FN", or "LF".

Notes:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. For door reinforcement see template 7400-0000.
6. Prepare mounting holes when installing trim.
7. 502(F), 504(F), and 505(F) trim require 3-1/2 (89) or wider door stiles.
8. Provide internal door support adequate to prevent door deformation from bolting trim to the device.
9. Template applies to 508F.

**502(F), 503(F), 504(F), 505(F), 506(F), 507(F), 508(F)
& 509(F) Narrow Escutcheon Trim**
With 7200, 7200M or 7200MF Series
Rim and Vertical Rod Exit Devices
Metal Door Preparation

Yale®

Yale Commercial Locks and Hardware

www.yalecommercial.com

TEMPLATE NUMBER

7400-0502

DATE

8-99